



# Hydro-Mixer XL Plumbing Diagram



#1 – Manual flush valve, allows you to flush/rinse your system w/ fresh water. It determines whether you pull water or SH through the CHEM valve on the Hydro-Mixer. (Optional remote rinse module available in lieu of manual)

#2 – Mixed solution through into pump

#3 – Bypass hose needs to be a minimum of 25' long. **Bypass time limit to be 10 mins. MAX.** System damage could occur if bypass is sustained for said duration

- Flush valve can mount directly to chem tank or remotely
- Water & chem supply lines should be of similar length for accurate and consistent metering
- Water supply for flush valve and water valve should be dedicated. Do not tee into other lines
- Always use strainers on pickup lines in tanks