



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

---



---

**BEPOWEREQUIPMENT**


**.COM**



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## CRANKCASE




| REF # | DESCRIPTION       | QTY | BE PART #  |
|-------|-------------------|-----|------------|
| 1     | MAGNETIC DIPSTICK | 1   | 85.561.021 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## ENGINE STARTER




| REF # | DESCRIPTION     | QTY | BE PART #  |
|-------|-----------------|-----|------------|
| 1     | RECOIL ASSEMBLY | 1   | 85.561.022 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## VALVE COVER




| REF # | DESCRIPTION                  | QTY | BE PART #  |
|-------|------------------------------|-----|------------|
| 1     | CYLINDER HEAD COVER & GASKET | 1   | 85.561.094 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## SPEED ADJUSTMENT BASE PARTS




| REF # | DESCRIPTION   | QTY | BE PART #  |
|-------|---------------|-----|------------|
| 1     | IDLE SOLENOID | 1   | 85.561.028 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## CARBURETOR ASSEMBLY




| REF # | DESCRIPTION         | QTY | BE PART #  |
|-------|---------------------|-----|------------|
| 1     | CARBURETOR ASSEMBLY | 1   | 85.561.023 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## AIR CLEANER ASSEMBLY




| REF # | DESCRIPTION          | QTY | BE PART #  |
|-------|----------------------|-----|------------|
| 1     | AIR CLEANER ASSEMBLY | 1   | 85.561.024 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## MUFFLER PARTS




| REF # | DESCRIPTION      | QTY | BE PART #  |
|-------|------------------|-----|------------|
| 1     | MUFFLER & GASKET | 1   | 85.561.095 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## AVR AND BRUSHES




| REF # | DESCRIPTION     | QTY | BE PART #  |
|-------|-----------------|-----|------------|
| 1     | AVR AND BRUSHES | 1   | 85.561.025 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## FRAME PARTS




| REF # | DESCRIPTION         | QTY | BE PART #  |
|-------|---------------------|-----|------------|
| 1     | COLD WEATHER PRIMER | 1   | 85.561.005 |
| 2     | CO ALARM            | 1   | 85.561.006 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## WHEEL AND HANDLE SET




| REF # | DESCRIPTION          | QTY | BE PART #  |
|-------|----------------------|-----|------------|
| 1     | WHEEL AND HANDLE SET | 2   | 85.561.026 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## FUEL TANK ASSEMBLY




| REF # | DESCRIPTION     | QTY | BE PART #  |
|-------|-----------------|-----|------------|
| 1     | FUEL TANK PARTS | 1   | 85.561.027 |



# PARTS BREAKDOWN GENERATOR

MODEL:BE9000

## CONTROL PANEL



| REF # | DESCRIPTION                    | QTY | BE PART #  |
|-------|--------------------------------|-----|------------|
| 1     | ENGINE SWITCH                  | 1   | 85.561.151 |
| 2     | LED SWITCH                     | 1   | 85.561.136 |
| 3     | LED LIGHT                      | 1   | 85.561.137 |
| 4     | AC RECEPTACLE(GFCI) AC125V/20A | 3   | 85.561.146 |
| 5     | PROTECTOR 20A                  | 3   | 85.561.141 |
| 6     | AC RECEPTACLE AC125V250V/30A   | 1   | 85.561.145 |
| 7     | PROTECTOR 30A                  | 2   | 85.561.149 |
| 8     | CIRCUIT BREAKER 2P-27A         | 1   | 85.561.152 |
| 9     | VOLTAGE SWITCH                 | 1   | 85.561.143 |
| 10    | DC12V                          | 1   | 85.561.148 |
| 11    | DC THERMAL PROTECTION 8A       | 1   | 85.561.147 |
| 12    | IDLE SWITCH                    | 1   | 85.561.153 |
| 13    | RECTIFIER BRIDGE               | 1   | 85.561.149 |
| 14    | DC08                           | 1   | 85.561.142 |

# **BE**

**POWER EQUIPMENT**

---

**If you need technical assistance call:**

**1-866-850-6662**

**(8:00am - 4:30pm PST, Mon - Fri)**